


For proper printing of this form, set the computer's graphic resolution to 800x600 or higher.

For best results, use a high-quality printer that can produce solid, black bars.

Cut paper evenly on each side to fit the note guide you are using.

DIP 1, Position 1 (on micro board) must be switched ON to configure the GBAII with this sheet.

INSERT GBA PROGRAM SHEET European Note Guide
← Note: This card is compatible with firmware version 0245 and above



Turn Check for Extra Notes Returning ON

← INSERT

The diagram shows a barcode consisting of vertical black bars of varying heights. The bars are arranged in a sequence that encodes the program sheet information. The text 'Turn Check for Extra Notes Returning ON' is positioned below the barcode, indicating a specific setting for the GBAII hardware.